

DROLL YANKEES®

The World's Best Bird Feeders®

Seed Saver (X-1) Feeder

All Droll Yankees Feeders can be disassembled for easy cleaning or replacing parts.

Cleaning: Please for the sake of the birds, keep your feeders clean! Dirty feeders can harm the birds. Use a mild soap and water solution and a soft bristle brush for thorough and simple cleaning. Dry completely before filling with seed, fruit, mealworms or suet.


Disassemble

1. Turn the dish counter-clockwise (viewed from bottom) to remove threaded end of 10" rod from the metal insert located in the center of dish.
2. Release the black collar and set screw by turning the set screw counter-clockwise and remove by sliding black collar and set screw down the 10" rod.
3. Slide dome down 10" rod and remove O-ring.

Assemble

1. Install O-ring just underneath the hook on 10" rod.
2. Slide dome up the 10" rod to the O-ring.
3. Install black collar and set screw by sliding it up the 10" rod to the dome and tighten the set screw.
4. Insert the threaded end of 10" rod into metal insert which is located in center of dish and turn dish clockwise (viewed from bottom) until tight.
5. The dome can be raised or lowered to desired height by adjusting the black collar and set screw on the 10" rod.

Note: O-ring should always be positioned against top of dome to keep water from dripping down 10" rod into the dish.



Droll Yankees Inc. • drollyankees.com
Customer Service: drollbird@drollyankees.com
(860) 779-8980 or (800) 352-9164