

DROLL YANKEES[®]

The World's Best Bird Feeders[®]

The Cutest Chickadee Feeder (CUTE)

All Droll Yankees Feeders can be disassembled for easy cleaning or replacing parts.

Cleaning: Please for the sake of the birds, keep your feeders clean! Dirty feeders can harm the birds. Use a mild soap and water solution and a soft bristle brush for thorough and simple cleaning. Dry completely before filling with seed, fruit, mealworms or suet.


Disassemble

1. Turn the dish counter-clockwise (viewed from bottom) to remove threaded end of 8.5" rod from the metal insert located in the center of dish.
2. Release the spring rod clip by squeezing with thumb and pointer finger and slide the spring rod clip down the 8.5" rod.
3. Slide dome down 8.5" rod and remove O-ring.

Assemble

1. Install O-ring about 2 inches down from hook on the 8.5" rod.
2. Slide dome up the 8.5" rod to the O-ring.
3. Install spring rod clip by squeezing with thumb and pointer finger and slide it up the 8.5" rod to the dome and release.
4. Insert the threaded end of 8.5" rod into metal insert which is located in center of dish and turn dish clockwise (viewed from bottom) until tight.
5. The dome can be raised or lowered to desired height by adjusting the spring rod clip on the 8.5" rod.

Note: O-ring should always be positioned against top of dome to keep water from dripping down 8.5" rod into the dish.



Droll Yankees Inc. • drollyankees.com
Customer Service: drollbird@drollyankees.com
(860) 779-8980 or (800) 352-9164