

ULTIMATE YARD SYSTEM

No Trees? No Problem! With our **Ultimate Yard System** you can hang bird feeders, plants, wind chimes, and more anywhere in your yard!

Installation:

Auger

Place the extensions on the three legs of the auger. In a flat area of your yard, hold the auger erect with the auger tip on the ground. Turn the auger clockwise by the extension legs, using them as levers to screw the auger into the ground. Be sure to keep the auger perpendicular to the ground. Turn until the extension legs are flush against the ground and the installation is stable.

Pole

- Insert Red Pole Shims into each grooved/swaged end of pole sections (new products will already have these installed).
- Install one of the two grooved/swaged pole sections, grooved/swaged end facing up, into the pole auger. Install the second pole, open end onto the grooved/swaged end of the first pole. Place third pole which has two open ends onto the second pole.
- Tighten the thumb screw in the auger stem to keep the pole in place.

Triple Pole hook

• Slide the collet onto the pole, threaded end up, to the desired position. Slide the hook holder onto the collet, being careful to align the raised section on the collet with the key hole in the hook holder. Insert the 12 inch hooks into the slots. Tighten the collet knob on the threads of the collet to secure the hook holder in place.

Pole Adapter

• Finally, insert the clear threaded adapter into the top of the pole threaded end facing up. You can screw the adapter into the base of a Droll Yankees tube feeder, the X-1, Dorothy's Cardinal Feeder, or the H8 Hummingbird feeder. This allows quick and easy removal of the feeder from the top of the pole for refilling. If you do not mount a feeder on top, leave the adapter in the pole to keep water from collecting in the pole. (The pole adapter can also be used with a tray by placing tray on the adapter and then attaching the feeder.)

Last Step

The stability of your pole and auger will depend in part on the composition of your soil. If
installed on a slope, shim the extension legs with a rock or a piece of wood to make the pole
straight.

Droll Yankees Inc. • drollyankees.com Customer Service: drollbird@drollyankees.com (860) 779-8980 or (800) 352-9164