



CJM13BLP feeder illustrated

The New Generation[®] Peanut Feeder with binding post barrel & screw

Droll Yankees feeders can be disassembled for easy cleaning and part replacement.

Cleaning: *Please for the sake of the birds, keep your feeders clean!* Dirty feeders can harm the birds. Use a mild soap & water solution and a soft brush for thorough, simple cleaning. Dry completely before filling with peanuts.

Disassemble

1. Remove the top cap by sliding the top cap halfway up the bail wire which will allow the top cap with bail wire to fall to the side. Gently pull each end of the bail wire out of the bail rod.
2. Squeeze the wire cage, slightly oblong in shape, horizontal with the bail rod, and reach inside the wire cage and remove the bail rod.
3. Remove the base by unscrewing the binding post screw and sliding the binding post barrel out from the opposite side.

Assemble

1. Position the wire cage with the full size squares at the top, and the half size squares at the bottom. Turn the wire cage so the seam on the wire cage will be positioned at the back of the feeder.
2. Install the bail rod by squeezing the top of the wire cage, slightly oblong in shape, inserting the bail rod into the 5th square from the top on each side of the wire cage. Needle nose pliers may be required to enlarge the squares, and also to squeeze the wire back tightly around the bail rod to hold the bail rod secure. Squeeze the wire cage back into a circular shape.
3. Place the wire cage on the base. Follow the row at the end of the bail rod down the wire cage to the bottom. Turn the base to align the hole in the base with that square.
4. Slide the binding post barrel through the square of the wire cage and the hole in the base to the opposite side. Screw the binding post screw into the binding post barrel.
5. Replace the top cap by inserting each end of the bail wire into the bail rod and slide the top cap down into place on the wire cage.

Droll Yankees Inc. • www.drollyankees.com
Customer Service: drollbird@drollyankees.com
(860) 779-8980 or (800) 352-9164

